

	4-e Humidity	4-d Wipe craters with acetone soaked rag to remove wax. Repour. 4-e Range should be less than 35%
5 Cured surface has "oil-slick"	5 High Humidity	5 Sand lightly, wipe and repour when humidity is below 60%. Use dehumidifier during rainy season.
6 ARISTOCRAT coating is thick on one side of project, thin on the other.	6 Work surface or project not level.	6 Use carpenter's level to check work surface. Use same height props under project. Sand, wipe, and repour.
7 ARISTOCRAT delaminates (separates from project)	7-a Incompatible sanding sealer or coating used under ARISTOCRAT. 7-b Stained or painted surface not dry. Wood has not been dried properly 7-c If delamination occurs only on edges, wax used to ease drip removal may have gotten on sides on project 7-d Power sanding into coated edges may cause delamination.	7-a The sealer which will provide the best adhesion is a brush coat of ARISTOCRAT SEAL COAT. To remedy, pull up cured delaminated coating. Sand down to clean wood, rounding sharp edges. Wipe down with acetone. Brush on seal coat of ARISTOCRAT. Four final coat in 8-24 hours. 7-b Use wax free stains. Allow stains and paints to dry thoroughly before coating with ARISTOCRAT. Use only properly dried woods. 7-c When using paste wax on underside, be careful not to get on sides or top of project as ARISTOCRAT will not stick permanently to grease or wax. 7-d If power sanding off drips, sand from coating edge to unfinished underside of project.
8 Stored resin has crystallized.	8 Temperature extremes occasionally will "shock" the resin side of polymer coatings in crystallizing.	8 Place closed resin bottle in hot tap water until crystals melt. Allow to cool to room temperature before combining with hardener. Store unused resin and hardener at room temperature. (70 deg F)
9 Mixed ARISTOCRAT sets up in just 5 or 10 minutes.	9 Resin and hardener are at too high a temperature.	9 Maximum pot life or working time is achieved when product is stored and poured at 65-70 deg F.
10 Cured surface has become dull, chipped, or scratched	10 Improper cleaning, abusive treatment.	10 If only dull and mildly scratched, use warm water, mild detergent and scrubber safe TEFALON to clean. Rinse and dry with a soft cloth. A coat of carnauba wax may be applied to bring back gloss. If badly chipped and scratched, sand with fine grit sand paper. Wipe with acetone on lint free rag to remove any wax or grease. Repour entire surface.